

I. AMENDMENTS

In the Specification:

Please replace the paragraph beginning on page 5, line 21 with the following paragraph:

The terms "components", "contaminants" and "impurities", as used herein are meant to include (i) materials having molecules that exhibit vibration energies in the range of 3×10^{14} - 12×10^{14} Hz, (ii) materials containing OH, CH, SH, CO and NH bonds and (iii) volatile organics.

Please replace the paragraph beginning on page 8, line 18 with the following paragraph:

As stated above, the analyzer 52 of the invention is adapted to determine the presence of trace components and contaminants in the cryogenic liquid. According to the invention, the determination of a trace component or contaminant is preferably accomplished by conducting a first scan of the base cryogenic liquid to ~~establish~~ obtain a first absorption (or energy) spectrum having a plurality of wavelengths that correspond to a first reference energy (i.e., absorption energy). A second scan of at least one target material known impurity (i.e., component or contaminant) is then conducted to determine an impurity absorption (or energy) spectrum associated with the target material known impurity, the impurity energy spectrum having a plurality of wavelengths that correspond to a neat impurity reference. The first and second scans preferably comprising near infrared light in the range of 900- 2200 nanometers.

Please replace the paragraph beginning on page 8, line 26 with the following paragraph:

The first absorption spectrum and impurity absorption spectrum (or spectra) are then stored in the processing means 54 memory. During on-line analysis, ~~[[the]]~~ a cryogenic liquid sample having a cryogenic liquid and a target impurity is scanned while the sample is contained in a selected cell (i.e., 37, 32a, 32b) to obtain the sample absorption (or energy) spectra, the sample spectra including an energy spectrum associated with the cryogenic liquid and a target impurity energy spectrum associated with the target impurity. The target impurity energy spectrum having a plurality of wavelengths that correspond to a target energy reference. The sample absorption spectra are then compared to the stored absorption spectra via the processing means 54 to distinguish among and ~~confirm the presence of~~ identify the cryogenic liquid sample absorption spectrum associated with the target material impurity, the sample absorption spectrum

~~associated with impurity having a second reference energy.~~ The method thus provides accurate and reliable identification of a trace material in a cryogenic liquid sample.